LED Lamp Wall Sconce

601021-LEDINSTALLATION SHEET

- Remove the fixture from its original packaging. Remove the canopy mounting plate from within the canopy and attach it to the electrical junction box, using the two screws provided in the hardware package.
- Push the canopy mounting screw through the center hole of the metal cover plate, then feed the electrical wires, from inside the electrical box, through the hole in the metal cover plate. Once this is complete you can (2a) screw on the provided washers and nuts until tight, (2b) secure the canopy back plate using the screws provided in the hardware package.
- Attach the canopy to the canopy back plate, which is attached to the electrical junction box. First attach all wiring with the provided marrets (white to white "N", black to black "L", ground to ground "G"). Align the holes on the sides of the canopy to the holes on the canopy back plate. Once aligned, screw in the two screws provided to secure the canopy to the back plate.
- Gently place the acrylic cover over top of the canopy. Then, align the two holes on each end of the acrylic to the holes on the ends of the canopy. Once aligned, screw in the two screws provided to secure the cover to the canopy (do not over tighten).
- You have now completed the installation of your fixture, please enjoy.

START FROM HERE

- Make sure power is completely off at the fuse box.
- Have your fixture installed by a qualified licensed electrician
- Prepare everything in clear area.
- Wear gloves at all times during this installation.
- Read instructions carefully before you start assembly.
- Keep this instruction sheet for future reference.

Technical Support: 1-877-452-6858

Please Note:

- All Kuzco LED fixtures come with pre-wired LED module(s).
- Unless instructed to do so, please do not touch any part of the LED module(s) as any unnecessary contact with the module could cause permanent damage.
- For dimming, an ELV (Electronic Low Voltage) dimmer is required.



