

- 1.** Remove the fixture from its original packaging. Remove the canopy mounting plate from within the canopy and attach it to the electrical junction box, and wall, using the two screws provided in the hardware package.
- 2.** Attach the canopy to the mounting plate which is attached to the electrical junction box on the wall. First attach all wiring with the provided marrets (white to white "N", black to black "L", ground to ground "G"). Push the screws through the canopy plate so they are poking through, once this is complete you can screw on the decorative nuts until tight.
- 3.** You can now install the T-10 light bulb of the correct wattage.
- 4.** Before installing the glass cover onto the fixture, please use the plastic adjustment screw to help achieve the desired position of the glass cover when it comes to rest on the fixture. (Turning the plastic screw clockwise will move the bottom of the glass away from the wall. Whereas, turning the plastic screw counter clockwise will move the bottom the glass closer to the wall.) During the adjustment process you may need to install and remove the glass cover a number of times before its desired position is achieved.
- 5.** Install the glass light cover onto the fixture by sliding the glass cover into place along the glass receiver bar installed on the canopy of the fixture.
- 6.** You have now completed the installation of your fixture, please enjoy.

START FROM HERE

- Make sure power is completely off at the fuse box.
- Have your fixture installed by a qualified licensed electrician
- Prepare everything in clear area.
- Wear gloves at all times during this installation.
- Read instructions carefully before you start assembly.
- Keep this instruction sheet for future reference.

Technical Support: 1-877-452-6858

