## **LED Exterior Wall Sconce**



## START FROM HERE

- Make sure **POWER** is **COMPLETELY OFF** at the fuse box
- Have your fixture installed by a qualified licensed electrician
- Prepare everything in a clear area
- Wear gloves at all time during this installation
- Read instructions carefully before you start assembly
- Keep this installation sheet for future reference

**Technical Support:** 1-855-855-8926

## Please Note:

- This Kuzco LED fixture comes with pre-wired LED module(s)
- Unless instructed, Do Not touch any part of the LED module(s) as any unnecessary contact with the module could cause permanent damage
- Use ELV (Electronic Low Voltage) type of dimmer for dimming application

- 1. Remove the fixture from its original packaging
- 2. Remove the mounting plate (1c) from within the fixture (2a) by loosening four screws (2b)
- **3.** Attach the mounting plate **(1c)** to the electrical junction box **(1a)**, using the two screws **(1e)** provided in the hardware package.
- **4.** Make proper electrical connections (black to hot "L", white to neutral "N", ground to "GND") with wire nuts **(1b)** provided in hardware package
- **5.** Attach the fixture (2a) onto the mounting plate (1c) and secure with four screws (2b)
- **6.** To prevent moisture from entering the outlet box and causing a short, seal around the top and side perimeter between the fixture and the wall surface with weather resistant caulking (see illustration 1). The space at bottom should be left un-caulked to prevent moisture build-up.

## Illustration 1





