LED Lamp Wall Sconce

WS6116 INSTALLATION SHEET

Please Note:

- All Kuzco LED fixtures come with pre-wired LED module(s).
- Unless instructed to do so, please do not touch any part of the LED module(s) as any unnecessary contact with the module could cause permanent damage.
- For dimming, an ELV (Electronic Low Voltage) dimmer is required.
- Remove the fixture from its original packaging. Remove the mounting plate (1a) from within the canopy and attach it to the electrical junction box, and wall, using the two screws provided in the hardware package
- Remove the canopy plate (2a) from fixture by untightening all set screws (2b) on 2-top and 2-bottom of fixture
- Attach the canopy to junction box on the wall.

 First attach all wiring (3a) with the provided marrets (white to white "N", black to black "L", ground to ground "G").

 Secure the canopy plate onto the mounting plate using the two nuts (3b) provided. Once this is complete push fixture onto canopy and tighten all set screws (2a) (2 top 2 bottom) till they are tight.
- You have now completed the installation of your fixture, please enjoy.

START FROM HERE

- Make sure power is completely off at the fuse box.
- Have your fixture installed by a qualified licensed electrician
- Prepare everything in clear area.
- Wear gloves at all times during this installation.
- Read instructions carefully before you start assembly.
- Keep this instruction sheet for future reference.

Technical Support: 1-877-452-6858

